



Towing Jacket



Thank you for choosing to purchase the Pro-tec Towing Jacket to protect the front of your Caravan. The Jacket is made from our exclusive Caravanshield™ fabric, which is guaranteed not to scratch your windows or bodywork and will offer exceptional protection against stone chips and road dirt.

Before fitting, please ensure that the front of your 'van is clean. If grit becomes trapped between the cover and the front of the caravan, there is a risk of scratching.

Towing Jacket's are designed for towing purposes only.

Fitting the Towing Jacket couldn't be easier:

- 1 - Unpack your Towing Jacket from the storage bag and identify the two sides. As you are facing the front of your van, the section of the Towing Jacket which bears the Pro-tec logo goes to the left.**
- 2 - Slide the left piece into the left awning channel with the Pro-tec logo to the top. Slide the right piece into the right awning channel.**
- 3 - If you have received 2 awning stoppers with your cover please fit these at the bottom of the awning channels just underneath where the cover is sitting and secure them in the channel by tightening them. (This only applies to certain models)**
- 4 - Zip the two sections together.**
- 5 - Attach the valance hooks to the underside of the caravan fascia.**
- 6 - Attach the supplied A-Frame strap to the buckles on each section of the Towing Jacket, passing the strap underneath the A-Frame assembly.**
- 7 - If you have received 2 white SNAD fasteners with your cover attach these to the 2 press-studs at the top of the cover and remove the backing to adhere these to the caravan. (This only applies to certain models).**

See over page for details of the features of your Towing Jacket

Your Towing Jacket is armed with a number of features to make life easier for the savvy caravanner. We have designed the Jacket to allow access to the caravan grab handles, locker box and windows, all without having to remove the cover from the front of your caravan.



If you opted for Jacket Pockets, underneath each Jacket Pocket you will find access to the caravan grab handles.



To reveal the caravan windows, simply unfasten the zip from the top down to the required height. The 2 sections naturally fold out of the way of the windows.



To gain access to the locker box (if applicable on your caravan), unfasten the velcro strip located at the bottom of the awning channel on either side of the Jacket, unzip the centre panel from the bottom up and lift the 2 sections. If you need to gain access to the locker box for longer periods of time, the 2 sections can be held out of the way via the reflective Velcro mechanisms.