



Eriba Towing Jacket



Thank you for choosing to purchase the Pro-tec Towing Jacket to protect the front of your Eriba Caravan. The Jacket is made from our exclusive Caravanshield™ fabric, which is guaranteed not to scratch your windows or bodywork and will offer exceptional protection against stone chips and road dirt.

Before fitting, please ensure that the front of your 'van is clean. If grit becomes trapped between the cover and the front of the caravan, there is a risk of scratching.

Included with your Towing Jacket, you will find 4 x SNAD® fasteners in a separate plastic bag. These are detailed in steps 4 & 5.

- 1 - Unpack your Towing Jacket from the storage bag and identify the two sides. As you are facing the front of your van, the section of the Towing Jacket which bears the Pro-tec logo goes to the left.**
- 2 - Slide the left piece into the left side of the awning channel above the window, with the Pro-tec logo to the top. Slide the right piece into the right side of the awning channel, then pull the 2 sections together so that they meet in the middle.**
- 3 - Zip the two sections together.**
- 4 - With the two sections zipped together, locate the press-studs on the outer edges of the Towing Jacket. Attach the supplied adhesive SNAD® fasteners to the press-studs.**
- 5 - Position the Towing Jacket correctly, ensuring that the central zip is indeed in the centre and the A-Frame opening sits snugly around the Eriba's A-Frame assembly. Only once you are happy with the position of the Towing Jacket, remove the backing from the adhesive SNAD® fasteners and press firmly against the caravan body in the required position. If you make a mistake in the positioning of the SNAD® fasteners, they can be removed by levering a credit card sized object underneath. This step is only required the first time you fit the Towing Jacket. In subsequent fittings, attach the Towing Jacket to the previously sited SNAD® fasteners via the press-studs.**
- 6 - Attach the valance hooks to the underside of the caravan fascia.**
- 7 - Attach the supplied A-Frame strap to the buckles on each section of the Towing Jacket, passing the strap underneath the A-Frame assembly.**
- 8 - Your Towing Jacket is now ready for action!**

Your Towing Jacket is armed with a number of features to make life easier for the savvy caravanner. We have designed the Jacket to allow access to the caravan grab handles, locker box and windows, all without having to remove the cover from the front of your caravan.

Underneath each Jacket Pocket, you will find access to the caravan grab handles.

To reveal the caravan windows, simply unfasten the zip from the top down to the required height. The 2 sections naturally fold out of the way of the windows.

To gain access to the locker box, unfasten the velcro strip located at the bottom of the awning channel on either side of the Jacket, unfasten the zip from the bottom up and lift the 2 sections. If you need to gain access to the locker box for longer periods of time, the 2 sections can be held out of the way via the velcro mechanism.