



Fitting Instructions – Generic

What you will find in your Pro-Tec Towing cover

- 1 x Main Panel
- 2 x Side Panel's
- Tear Aid DIY kit for reflectors

These fitting instructions are aimed as a guide to the best way that we've found to the fit your Protec cover.

Before starting it is essential that you remove any sharp objects that may be on your caravan, as well as making sure your caravan is clean.

With all of our generic covers it is essential that with the DIY kits provided you mark of the space for your reflectors, this will enable you to cut out the needed space to make your towing cover road legal.

1. First of all take one of the side panels, slide this up the awning channel with the white side to your caravan. Then do the same on the other side.
2. Starting at the top on one side and clip the straps together, attach the top strap at the other side and work your way down.
3. Making any adjustments needed to centralise the cover, then take strap attached to your cover and clip into place going under the A frame.

Your Pro-Tec Cover is now ready to use.

If you need any further information please do not hesitate to contact