



Motorhome Cover



These fitting instructions are aimed as a guide to the best way that we've found to fit your Protec cover.

Before starting it is essential that you remove any sharp objects that may be on your motorhome, and ensure your motorhome is clean and free of any puddles of water. Failure to do so can result in damage to your motorhomes paintwork, as dirt can get trapped between the cover and the van.

Fitting Instructions

- 1 - The first step is to make sure your motorhome is clean, free of all dirt and dust, also for extra protection we ask that your van is reasonably dry with no puddles of water. This is essential to ensuring that nothing is trapped between your motorhome and cover, preventing scratches and marks. However due to the soft inner lining there is no need to do this on your windows.
- 2 - Now unpack your bag and you will find your new motorhome cover, a spare piece of fabric, straps and two extending poles.
- 3 - Thanks to our exclusive Easy-Fit System installing your Pro-tec cover is easier than ever. Firstly, locate the rear of the cover and ensure the roll-up Easy-Fit panel is rolled open. Then locate the 2 D-rings at the rear of the cover and insert a pole into each D-ring.
- 4 - Starting at the front of the motorhome use the poles to lift the cover up and over the roof of the motorhome.
- 5 - Pull the cover along the length of the motorhome until you reach the end. Roll down the Easy-Fit panel once you have reached the rear of your van.
- 6 - Secure the cover down by securing the straps provided to the buckles which are along the width of the cover. There will be 2 extra-long straps with your cover also, secure these to the buckles on the front and back of your motorhome *there is also a loop at the rear of the cover which you can thread the strap through for additional tightening at the easy-fit if needed*. Tension the straps as you see fit, taking care not to overtighten.

Care Instructions

Clean the cover using warm water with a soft brush, a hosepipe may be used but we do not advise the use of power washers.
DO NOT use any detergents or chemicals as this will block the pores and affect the hydrophobic properties of the fabric. However, if you have any stubborn stains that will not be removed with just warm water, you can add soap flakes (the type you would use to hand-wash clothing) to the warm water to aid the washing.